

Student Center Conference Room (Back of Building)

Power on Screen:

Press Power Button on the left side of the screen



OR Power button on screen remote control:



Screen Options



Whiteboard – acts as a white board using the markers and erasers located on the screen bottom

Screen Share – you can share items off of your phone to the screen

Input – select the screen physical input -> currently only HDMI1 is in use (explained later)

Files Library – not currently used

Google – several google applications available using just the screen (no computer needed)

Play Store – used to purchase additional Android apps for the screen

At any time, you can return to this screen by pressing the home button in the middle of the bottom of the screen



Or use the remote home button




Turning on the Computer

Press the power button on the computer




On the Screen, select Input



Or use the remote to select input



Then select the HDMI 1 option



Use the keyboard and mouse on the table with the computer. Plug USB drives into the computer as needed.

There is a pointer / clicker on the table as well, which can be used with Powerpoint to advance slides.


When finished, please power down computer. Turn off Screen using power button on side of screen or the remote control.

Using the Screen as a Whiteboard


On the input screen, select the Whiteboard option. You can then draw and erase on the board using the pens and erasers located along the bottom of the screen.

Using Android applications on the Screen


Select the Google options from the home screen



You will then have the following options:



If you wish to go to another application or are finished, press the Home button in the middle of the bottom of the screen or on the remote



When finished PLEASE power down the screen using the power button on the side of the screen OR the power button on the remote.